MADE IN CHINA
Manufactured by WISMEC

Manufacturer: SHENZHEN WISMEC ELECTRONICS CO., LTD
Address: 4F, 5B Building, Yong Feng Industrial Park,
Shiyan Street, Bao'an District, Shenzhen, China
Contact: info@wismec.com

REULEAUX
95% Satisfied | Proof

Reuleaux RX GEN3 Dual Overview

How to use

1. **Power On/Off**: Push forward the battery cover and pull two high-rate 18650 cells into the battery body. Ensure the positive terminals face the atomizer. Push the battery cover back to close.
2. Please adjust the wattage or power gear to match the atomizer you used before using.
3. Press the button 5 times quickly to lock or unlock the screen.
4. **Stealth function**: While the device is on, simultaneously hold the fire button and the left regulatory button. The screen will turn off. Repeat to restore.
5. **Key lock function**: While the device is on, simultaneously press the fire button and the right regulatory button. This will switch between Key Lock and Key Unlock modes.
6. **Firmware upgrade**: A micro USB cable can be used for charging and upgrading firmware. It is better to be upgraded through a computer rather than a power bank.
7. **Switch the display mode**: By pressing the left and right regulatory buttons simultaneously in shutdown state, the display mode can be switched. There are 4 modes in total: Mode 1, Mode 2, Mode 3, and Mode 4 (Off-screen).

Shift among VAPE/ AUTO-SUCTION MODE
Under the shutdown state, press the left regulatory button 3 times quickly to switch between VAPE ON, AUTO-SUCTION ON, and AUTO-SUCTION OFF. Please refer to the following instructions for more information.

VW Mode
In this mode, output wattage can be adjusted from 1W to 220W by pressing the regulatory buttons, right to

increase and left to decrease.

TC-SS Mode: The TC-SS function is suitable for SS316 coil.

TCR (NI, SS, TI) Mode: Under the TCR mode, you can choose the material of the coil you are using. Please choose the correct material before using. Otherwise, it may cause dry burning or damage to the coil.

The Setting of TCR Mode: In normal VAPE mode, press the fire button 5 times quickly to enter the TCR setting mode. (1) Press the left or right regulatory button to choose among TCR-NI, SS and Ti.
(2) Press the fire button to confirm the selected material.
(3) Press the left or right regulatory button to decrease or increase the temperature.
(4) Press the fire button to confirm.

Adjustable Preheat Function
Under the shutdown state, press the left regulatory button to set the first gear for 10 seconds as you prefer. Press the fire button and right regulatory button simultaneously to enter into the menu system. Press the fire button to enter the preheat setting. Press the left or right regulatory button to choose the preheat time. Options are from zero to five for 0 seconds, 1 second, 2 seconds, 3 seconds, 4 seconds, and 5 seconds.

Shutdown Function
Please consult with your WISMEC distributors for warranty policy. We are not responsible for any damage caused by improper operation.
The warranty is only valid for authentic WISMEC products within warranty period from date of purchase by customer.

with the fire regulatory button, right to increase and left to decrease.

Shift between TC and VW Mode: Under the shutdown state, it will continue to press the right regulatory button 3 times quickly to switch between TC mode and VW mode. Please be noted that the default temperature is benchmarked to the resistance (150°C) that will not change back to °F automatically and the temperature unit will not change to °F.

Temperature unit switch: Under the wattage and VW mode, press the right and left regulatory button 3 times quickly to switch between °C and °F. Please be noted that the default temperature unit is benchmarked to the resistance setting exactly correlates to temperature.

Shift among VAPE/ AUTO-SUCTION MODE: Under the shutdown state, press the right regulatory button 3 times quickly to switch between VAPE ON, AUTO-SUCTION ON, and AUTO-SUCTION OFF. Please refer to the following instructions for more information.

New atomizer installation: In TC mode, be careful to attach new atomizers that require resistance to below 0.05Ω. Please be noted that the default temperature is benchmarked to the resistance (150°C) that will not change back to °F automatically and the temperature unit will not change to °F.

Logo Mode
Under the shutdown state, press the left regulatory button 5 times quickly to enter the logo mode. Press the left or right regulatory button to choose among 7 logos. Press the fire button to confirm the selected logo. Press the fire button and the left regulatory button to choose the logo display duration. Options are from 1 second to 5 seconds.

Locking/Unlocking Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the locking function. Press the fire button and the left regulatory button to choose among locking and unlocking. Press the fire button to confirm.

Screen Saver Mode
Under the shutdown state, press the fire button and the left regulatory button simultaneously to enter into the screen saver mode. Press the fire button and the left regulatory button to choose among 7 screen savers. Press the fire button to confirm the selected screen saver.

Screen Rotation
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the screen rotation mode. Press the fire button and the left regulatory button to choose among 4 screen rotations. Press the fire button to confirm the selected screen rotation.

Puff Counting Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the puff counting mode. Press the fire button and the left regulatory button to choose among clear puff counting, total puff counting, and exit. Press the fire button to confirm.

Vaping Time Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the vaping time mode. Press the fire button and the left regulatory button to choose among clear vaping time, total vaping time, and exit. Press the fire button to confirm.

Battery Voltage Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the battery voltage mode. Press the fire button and the left regulatory button to choose among battery voltage and exit. Press the fire button to confirm.

Temperature Unit Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the temperature unit mode. Press the fire button and the left regulatory button to choose among °C, °F and exit. Press the fire button to confirm.

Resistance Unit Function
Under the shutdown state, press the fire button and the right regulatory button simultaneously to enter into the resistance unit mode. Press the fire button and the left regulatory button to choose among Ω, mΩ and exit. Press the fire button to confirm.

Coil Library
The resistance ranges of common types of coils are built in the coil library. Please choose the correct coil before using. Otherwise, it may cause dry burning or damage to the coil.

Coil Lock
The resistance of the coil will be locked after the coil is built. Please choose the correct coil before using. Otherwise, it may cause dry burning or damage to the coil.

Coil Unlock
Unlock the coil to change the coil.

Coil Resistance Calibration
Calibrate the resistance of the coil to ensure the accuracy of the coil resistance.

Restore Factory Settings
Restore the device to factory settings.

Regulatory Low Inverse
Under the shutdown state, press the left regulatory button 3 times quickly to enter into the regulatory low inverse mode. Press the left or right regulatory button to choose among ON and OFF. Press the fire button to confirm.

Regulatory Low Inverse
Under the shutdown state, press the left regulatory button 3 times quickly to enter into the regulatory low inverse mode. Press the left or right regulatory button to choose among ON and OFF. Press the fire button to confirm.

Shift among VAPE/ AUTO-SUCTION MODE
Under the shutdown state, press the left regulatory button 3 times quickly to switch between VAPE ON, AUTO-SUCTION ON, and AUTO-SUCTION OFF. Please refer to the following instructions for more information.

Logo Mode
Under the shutdown state, press the left regulatory button 5 times quickly to enter into