WISMEC

SINUOUS FJ200
User Manual

Manufacturer: WISMEC(SHENZHEN) ELECTRONICS CO., LTD.
Address: Room 901, Building 2-A Business Incubation Park, Guangming District, Shenzhen, Guangdong, China
Zone, Dongguan, Guangdong, China
Email: info@wismec.com

MADE IN CHINA
Manufactured by WISMEC

Sinuous FJ200 Overview



English

Product introduction
The Sinuous FJ200 is a fresh look at an internal Dual Battery Device. It fully dumps cues from the original Sinuous FJ200 and adds a new and improved chipset to the device. The FJ200 is a 200W temperature control device that is compatible with dual 18650 batteries. The device has a 0.91" OLED screen and is housed in a durable and ergonomic zinc alloy housing. The device is also equipped with a 5ml bottom fill tank that has a top fill system. The FJ200 is a great device for vapers looking for a powerful device that is compact and easy to use.

How to use
1. Turning on/off: Press the fire button 5 times in quick succession, the indicator light will flash 5 times to indicate the device is on or off. Alternatively, you can press the fire button and the + button at the same time.

2. Stealth function: While the device is on, simultaneously press the fire button and the left regulatory button. The unit will turn the screen display on and off.

3. Key lock function: While the device is on, simultaneously press the two regulatory buttons. The unit will lock/unlock the device's keys.

4. Micro USB port function: The micro USB port can be used for charging and upgrading firmware.

5. Switch the display mode: By pressing the left and right regulatory buttons simultaneously in shutdown mode, you can switch the display mode. Off, Regular, You can then use the screen from the bottom of page through this operation.

Shift among WATT/AUTO/TCR/TCR-SS/TCR Mode
Press the fire button 3 times to enter into the mode options. Then press the right regulatory button to switch between WATT, AUTO, TCR, TCR-SS, TCR Mode. Press the fire button to confirm the selection.
Under TCR Mode, when you enter the setting, press the left regulatory button to enter the Coil Resistance setting. Press the right regulatory button to adjust the coil resistance. Press the fire button to confirm the selection and return to the status to confirm.
In the menu, under setting can be adjusted from 100 to 2000W by pressing the regulatory button, right to increase and left to decrease.
Note: The TCR value in the TCR mode is suitable for SS316 coil.
TCR (W, MC, MC2): In TCR (Temperature Coefficient of Resistance) mode, users can set the parameters according to the TCR of coil.
1. Press the fire button 3 times to powered Off state, keep pressing the fire button and right regulatory button simultaneously, then you enter into the W (W) mode.
2. Press the left button to enter into the TCR (MC) mode by pressing TCR MC and MC2.
3. Press the fire button to confirm the mode you chosen.
4. Under TCR (MC) mode, press the left button to enter into temperature the parameter according to the TCR of coil.
5. Keep pressing the left button to the interface for about 10 seconds to confirm.

Following is the TCR value range for your reference:	
Material	**TCR value range**
Nickel	4000-6000
Titanium	3000-4000
SS (304, 316L, 316, 317)	600-1000

3. When using normal coil or the resistance of coil you used is higher than 1.5ohm in TC modes, the device will automatically switch to Watt.

Shift among Current, Puff and Time Mode: When the unit is in Watt mode, press the right regulatory button to enter into the Current, Puff and Time mode.

The Setting of Preheat Function:
1. Press the fire button 3 times and the left and right regulatory buttons simultaneously and then you enter the preheat setting menu.
2. Press the left regulatory to switch between preheat power and preheat duration.
3. Press the right regulatory button to increase or decrease the parameter.
4. Press the fire button to confirm the selection.

Adjustable Timeout Duration:
The device has a timeout feature that is allowed to set the timeout duration from 5 to 15 seconds as you prefer. Press the fire button 3 times and the left regulatory button simultaneously to enter into the menu options. Press the right regulatory button to enter the timeout duration setting. Press the left regulatory button to set the duration and press the fire button to confirm the selection and return to the status to confirm.

Auto Puff Function: The device has an auto puff function that will activate the device after 30 seconds of inactivity. This function can be turned on/off in the menu options.

Charging Protection (ESC): While charging, if the temperature of the device is higher than 65°, 45°display charging icon will flash to remind you. The device will stop charging when it is higher than 70°C/158°F.

While charging, when the temperature of the device reaches to 60°, 140°display the device reaches to 60°, 140°display the device reaches to 60°, 140°display