

Preheat Function

The following instruction is applicable to Reuleaux RX2/3, Reuleaux RX200S and Reuleaux RX75.

The newly added preheat function allows the device to heat up the coil quickly at a higher wattage, which is especially obvious when using with an RDA, RBA, RTA and so on. It can also prolong the coil's life and produce a better flavor.

How to use:

1. Long press the fire button and right regulatory button simultaneously to enter the menu.
2. Press the right regulatory button 2 times to enter the preheat setting menu.
3. Press the fire button to switch between preheat power and preheat duration.
4. Press the left or right regulatory button to decrease or increase the parameter.
5. Long press the fire button to confirm.