


WISMEC™



REULEAUX
— 250W —

Quick Guide

Reuleaux DNA250 Overview



Specification & Features

Size: 40*50*84mm

Thread type: 510 spring loaded thread

Cell type: High-rate 18650 cell (discharging current should be above 25A)

Output mode: TC/VW mode

Output wattage: 1-250W

Temperature range: 100-300°C/200-600°F (TC mode)

How to use:

1. Lock/Unlock: Unplug the magnetic back cover and put three 18650 cells into the battery body.

Press the fire button and the screen will display "LOCKED, CLICK 5X". Press the fire button 5 times in quick succession to lock and unlock the device.



2. Stealth function: While locked, press the fire button and down button simultaneously will switch to STEALTH MODE. In this mode, the display is off. In the same way to switch back to NORMAL MODE.



3. Power locked function: Under VW mode, pressing the up and down buttons simultaneously will place the device in POWER LOCKED mode. In the same way to exit POWER LOCKED mode.



4. Temp locked function: Under TC mode, pressing the up and down buttons simultaneously will place the device in TEMP LOCKED mode. In the same way to exit TEMP LOCKED mode.



Profiles Setting:

Reuleaux DNA250 allows you to save and select between eight groups of output settings. Each group of output settings is called a profile. In POWER LOCKED mode/TEMP LOCKED mode, double click the up or down button to cycle between profiles. Press the fire button to select the displayed profile.



VW Mode:

In this mode, you can adjust the wattage from 1W to 250W by pressing the up/down button.

Supplementary TC Mode Functions:

Temperature adjustment: Under TC mode, the temperature can be adjusted from (100-300°C or 200-600°F), up to increase and down to decrease.

Wattage adjustment: Under TEMP LOCKED mode, click the fire button 5 times in quick succession to enter Locked mode. Keep pressing the up and down buttons until the wattage appear. Press the up/down button to adjust the wattage.

Resistance locked function: In locked mode, press the fire and up buttons simultaneously to enter Resistance Lock mode. To disable resistance lock, repeat the procedure to unlock it.



New atomizer installation:

In TC mode, be careful to attach new atomizers that have cooled to room temperature. If a new atomizer has not cooled down before attaching, the temperature may read and protect incorrectly until the new atomizer cools.

When you connect a new atomizer or disconnect and reconnect your existing atomizer, the device will prompt you to confirm this change and a message will prompt "NEW COIL? YES + NO -".

Press the up button to confirm that a new atomizer has been attached. Press the down button to confirm that the same atomizer has been reconnected.



Indication and Protection:

Check Atomizer: The device does not detect an atomizer, the atomizer has shorted out, or the atomizer resistance is incorrect for the power setting.



Shorted: The atomizer or wiring are short circuited.

Weak Battery: The battery needs to be charged, or a higher rate battery needs to be used. If this happens, the DNA250 will continue to fire the atomizer, but will not be able to provide the desired wattage. The Weak Battery message will continue to flash for a few seconds after the end of puff.

Temperature Protected:

The heating coil reached the maximum allowed temperature during the puff. If this happens, the DNA250 will continue to fire, but will not be able to provide the desired wattage.

Ohms Too High: The resistance of the atomizer coil is too high for the current wattage setting. If this happens, the DNA250 will continue to fire, but will not be able to provide the desired wattage. The Ohms Too High message will continue to flash for a few seconds after the end of puff.

Ohms Too Low: The resistance of the atomizer coil is too low for the current wattage setting. If this happens, the DNA250 will continue to fire, but will not be able to provide the desired wattage. The Ohms Too Low message will continue to flash for a few seconds after the end of puff.

Too Hot: The DNA250 has onboard temperature sensing. It will shut down and display this message if the internal board temperature becomes excessive.

Warranty

Please consult with your WISMEC distributors for warranty policy. We are not responsible for any damage caused by user error.

This warranty is only valid for authentic WISMEC products within warranty period from date of purchase by the end user.

Warning

1. Keep out of reach of children.
2. This product is not recommended for use by young people, non-smokers, pregnant or breast-feeding women, persons who are allergic/sensitive to nicotine.

Contra-indication

1. Only have your product repaired by Wismec. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
2. Do not leave the product in high temperature or damp conditions, as this may damage the product. The appropriate operation temperature is within 0°C to 45°C while charging and -10°C to 60°C while in use.
3. Keep away from water.

Possible adverse effects

1. Use of this product may cause damage to health.
2. For people with adverse reaction after using this product, it is recommended to use the juice with lower nicotine content or no nicotine.



MADE IN CHINA
Manufactured by WISMEC

Manufacturer: WISMEC(DONGGUAN) ELECTRONICS CO., LTD.

Address: Room 401, Building 6 of Business Accelerator, No.24

Industry East Road, Songshanhu High-tech Industry Development Zone, Dongguan, Guangdong, China.

Contact: info@wismec.com